



SKP

LIMESCALE REMOVER | Eliminar Depósitos Calcáreos

DIRECTIONS

This product should be used at full strength for maximum effectiveness. Drain water from wash tank. Disconnect detergent or turn off dispenser so no detergent feeds into the machine. Add up to one gallon of S.K.P lime remover directly into wash tank. Using a spray bottle filled with S.K.P, spray directly onto heavy limescale buildup commonly found on rinse jets and machine inner walls. If using the spray bottle, wait 15 minutes so S.K.P has time to penetrate the buildup. Then, run the machine for 10 minutes. Make sure no detergent is feeding into the machine during this procedure. Drain the dish machine and refill with fresh water. Return the detergent feed to normal settings and wash as usual.

WARNING

This product is corrosive and can cause eye damage and skin irritation. Do not get in eyes, on skin, or on clothing. Protect eyes and skin when handling. Harmful if swallowed. Avoid contamination of food.

FIRST AID

For skin contact: Flush with plenty of fresh water for 15 minutes. If irritation persists SEEK IMMEDIATE MEDICAL ATTENTION. For eye contact: Flush with fresh water for at least 15 minutes, and seek medical attention. For contaminated clothes: Remove clothes and wash. If ingested: Drink large quantities of water. Avoid alcohol. Contact ChemTel Emergency Response Center (888)255-3924

INSTRUCCIONES

Este producto se debe utilizar toda su fuerza para lograr la máxima eficacia. Drene el agua del tanque de lavado. Desconecte detergente o desactivar dispensador de detergente por lo que no se introduce en la máquina. Agregue hasta un galón de SKP cal removedor directamente en el tanque de lavado. El uso de una botella de spray llena de SKP, rocíe directamente sobre la acumulación de sarro pesado que se encuentra comúnmente en los jets de aclarado y máquinas paredes interiores. Si se utiliza la botella de spray, espere 15 minutos por lo SKP tiene tiempo para penetrar en la acumulación. Luego, haga funcionar la máquina durante 10 minutos. Asegúrese de que ningún detergente se alimenta en la máquina durante este procedimiento. Drenar la máquina lavavajillas y vuelva a llenar con agua fresca. Devuelva el suministro de detergente a la configuración normal y lavar como de costumbre.

ALERTA

Este producto es corrosivo y puede causar daños en los ojos y la irritación de la piel. Evite el contacto con los ojos, la piel o la ropa. Proteger los ojos y la piel durante la manipulación. Nocivo por ingestión. Evite la contaminación de los alimentos.

FIRST AID

En caso de contacto con la piel: Lave con abundante agua fresca durante 15 minutos. Si la irritación persiste, buscar atención médica inmediata. En caso de contacto con los ojos: Enjuague con agua limpia durante al menos 15 minutos y busque atención médica. Para la ropa contaminada: Quitese la ropa y lavar. En caso de ingestión: Beber grandes cantidades de agua. Evite el alcohol. Contacto Centro de Respuesta a Emergencias ChemTel (888) 255-3924

KITCHEN & LAUNDRY DETERGENTS | EQUIPMENT SALES & SERVICE

1000 Linwood Street Brooklyn, New York 11208
Call 718-346-9111 | Fax 718-346-9133
www.CleanseTec.com

